

KR-BASE KIT INSTRUCTIONS

- 1) Remove pressure adjustment screw.
- 2) Drain board must also be removed if previously installed.
- 3) Remove the two C-clamp bases.
- 4) Install the two kit bases using the original 2 ¼ long bolts and hex nuts.
- 5) Re-install pressure adjustment screw and drain board.
- 6) Attach wringer to a solid flat surface using suitable hardware (not included).