

# DETAIL SHOP STANDARD OPERATION PROCEDURE

## EXPRESS SERVICES

STEP	PROCESS	PRODUCT LIST
<div style="font-size: 2em; color: red; font-weight: bold;">1</div> <p>ONE STEP CLEANER WAX ROTARY DA HAND</p>		<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>Shake well: For use with rotary with Polishing Foam pad WRF7 &amp; Backing Plate WRSBP Work one section at a time. Apply product onto a cool surface. Work in 2x2 foot areas. Work area until nearly dry. Wipe off excess with a clean Supreme Shine Microfiber X2020. Maximum 1600 rpm. Or use the MT300 with DMC5/6 pad at 4800 OPM's following same procedure.</p> </div> <div style="width: 45%;">  <p>QUICK DETAILER M6601 Secondary Bottle D9916, Label VSLM66</p>  </div> </div>
<div style="font-size: 2em; color: red; font-weight: bold;">1</div> <p>DRY WASH &amp; WAX</p>		<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>Wash vehicle with Rinse Free Express Wash &amp; Wax D115 at 4:1 and dry. Can be diluted up to 20:1 for light cleaning.</p> <p><i>*Must be diluted before use.</i></p> </div> <div style="width: 45%;">  <p>RINSE FREE EXPRESS WASH &amp; WAX D11501</p> </div> </div>
<div style="font-size: 2em; color: red; font-weight: bold;">1</div> <p>SPRAY WAX</p>		<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"></div> <div style="width: 45%;">  <p>SYNTHETIC X-PRESS SPRAY WAX D15601</p> </div> </div>
<div style="font-size: 2em; color: red; font-weight: bold;">1</div> <p>CARNAUBA WAX</p>		<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"></div> <div style="width: 45%;">  <p>HIGH TECH YELLOW WAX M2601</p> </div> </div>
<div style="font-size: 2em; color: red; font-weight: bold;">1</div> <p>PAINT Sealant</p>		<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>Apply M21 Synthetic Sealant with DA polisher set on 3800 OPM using a DFF5 Foam Finishing Pad (black). Apply product to entire vehicle then wipe off with X2020 Supreme Shine Microfiber Towel.</p> <p><b>Note: If the surface is not clean of contaminants make sure use Clay before apply it</b></p> </div> <div style="width: 45%;">  <p>Synthetic Sealant M21 Foam Finishing Pad 5" DFF5 Dual Action Machine MT300 Backing Plate DBP5 Supreme Microfiber Towel X2020</p> </div> </div>
<div style="font-size: 2em; color: red; font-weight: bold;">1</div> <p>ONE STEP CLEANER WAX ROTARY DA HAND</p>		<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>Shake well: For use with rotary or MT300. Work one section at a time. Apply product onto a cool surface. Work in 2x2 foot areas. Work area until nearly dry. Wipe off excess with a clean Supreme Shine Microfiber X2020. Maximum 1600 rpm for rotary or MT300 with DMC5/6 pad at 4800 OPM's following same procedure.</p> </div> <div style="width: 45%;">  <p>ULTRA POLISHING WAX D16601</p> </div> </div>
<div style="font-size: 2em; color: red; font-weight: bold;">1</div> <p>RINSE DRY &amp; PROTECT</p>		<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>No-buff application. Just spray on wet clean car, spread evenly, dry for base layer! Quick &amp; easy, application. SiO<sub>2</sub> molecule integrated into a polymer matrix provides extreme water beading protection.</p> </div> <div style="width: 45%;">  <p>Hybrid Ceramic Wax G190526 Supreme Microfiber Towel X2020</p> </div> </div>