


# Instructions for F200 Lint Hog™



General Information p. 2 Using the F200 Lint Hog<sup>™</sup> p. 3 Parts & Pricing p. 5 Notes p. 6

Model #
Serial #
Form # ADP-F200
7-16

### **GENERAL INFORMATION**

#### **Dear Customer:**

Congratulations on the purchase of your new Lint Hog™. Just one example of how Mytee Products Inc., is strive to keep you on the cutting edge with superior quality and technology.

Neglect or abuse of the Lint Hog<sup>™</sup> will void the warranty. With simple maintenance this product will give quality performance for many years to come.

If warranty questions arise, please consult user manual or get in touch with your distributor. If you have questions about maintenance, replacing parts or ordering parts, please call an authorized Mytee Products Inc. Service Center. To see an updated list, visit our website at www.mytee.com.

Before you begin using, please read your manual thoroughly.

Sincerely,

Mytee Customer Care Dept.

#### **Parts and Service**

Repairs, when required, should be performed by Mytee service personnel or Mytee authorized Service Center using Mytee original replacement parts and accessories. Call Mytee for repair parts or service. Please specify the Model and Serial Number when discussing your machine.

#### **Unpacking the Machine**

When the machine is delivered, carefully inspect the shipping carton and the machine for damage. If damage is evident, save the shipping carton so that it can be inspected by the carrier that delivered it. Contact the carrier immediately to file a freight damage claim.

#### After Use

 Disconnect the Lint Hog<sup>™</sup> from vacuum hoses at both ends, make sure the unit is emptied and cleaned for the next job.
Store indoors in a clean, dry place.

#### **Maintenance Schedule**

Make sure unit is emptied and cleaned after each use.


#### Troubleshooting

#### My Lint Hog™ isn't collecting debris.


1. Make sure the stainless steel filter has been emptied and cleaned. Check that your vacuum hoses are correctly attached to both hose inlets, and the wand and extractor. Also, make sure that your wand and extractor are in good working order.

#### **Machine Specifications**

Filter	12" stainless steel strainer basket
Inlets	One 2" male Cuff-Lynx™ connection and one 2" female Cuff-Lynx™
Construction	Durable roto-molded polyethylene
Product Weight	5 lbs.
Machine Dimensions	20.75" x 8" x 11.5"




### F200 LINT HOG™



Position the Lint Hog<sup>TM</sup> in line between the cleaning tool and the truckmount or portable extractor. Using vacuum hoses with 2" Cuff-Lynx<sup>TM</sup> hose connectors, connect the cap end of the Lint Hog<sup>TM</sup> to your cleaning tool and connect the female Cuff-Lynx<sup>TM</sup> end to your extractor or truckmount.

### F200 LINT HOG™ PARTS & PRICING



Part prices are subject to change.

## NOTES

